Алматы (7273)495-231 Ангарск (3955)60-70-56 Архангельск (8182)63-90-72 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 Благовещенск (4162)22-76-07 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Владивосток (423)249-28-31 Владикавказ (8672)28-90-48 Владимир (4922)49-43-18 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Иркутск (395)279-98-46 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Коломна (4966)23-41-49 Кострома (4942)77-07-48 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Курган (3522)50-90-47 Липецк (4742)52-20-81

Россия +7(495)268-04-70

Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Ноябрьск (3496)41-32-12 Новосибирск (383)227-86-73 Омск (3812)21-46-40 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Петрозаводск (8142)55-98-37 Псков (8112)59-10-37 Пермь (342)205-81-47

Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15 Розань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78 Севастополь (8692)22-31-93

Саранск (8342)22-96-24 Симферополь (3652)67-13-56 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Сургут (3462)77-98-35 Сыктывкар (8212)25-95-17 Тамбов (4752)50-40-97 Тверь (4822)63-31-35 Ярославль (4852)69-52-93

Киргизия +996(312)96-26-47

Томск (3822)98-41-53 Тула (4872)33-79-87 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59 Улан-Удэ (3012)59-97-51 Уфа (347)229-48-12 Хабаровск (4212)92-98-04 **Чебоксары** (8352)28-53-07 **Челябинск** (351)202-03-61 Череповец (8202)49-02-64 Чита (3022)38-34-83 Якутск (4112)23-90-97

Тольятти (8482)63-91-07

https://skamol.nt-rt.ru/ || sor@nt-rt.ru

### Improved indoor climate with SkamoWall






# Learn more about **SkamoWall**

Table of contents		
Improved indoor climate with SkamoWall		
Regulate damp problems with SkamoWall6		
Eliminate mold with SkamoWall 8		
All in one with SkamoWall		
Simple mounting with SkamoWall	盖为	
SkamoWall's expression		ALIAN
Preserve the architectural expression with SkamoWall . 16		
Screw strength with SkamoWall		
Production of SkamoWall		
Technical information about SkamoWall Board 22		
	The state of the s	
		-12,02200
		No. of Concession, Name of Street, or other Party of Street, or other
TO SECOND		The same of the sa
		TO THE OWNER OF THE OWNER OWNER OF THE OWNER OWNE
		PREPARE

# Improved indoor climate with SkamoWall



# Regulate damp problems with SkamoWall



# Eliminate mold with SkamoWall



# All in one with SkamoWall



### Simple mounting with SkamoWall



The following pages provide a more detailed explanation of how to mount SkamoWall.

Mounting SkamoWall can be explained briefly in six points that make it easy for both DIY projects and professional craftsmen.

1 Prepare the wall

Remove loose plaster, tar, paint residue and organic materials. In case of mould growth, clean the wall with a biocide product. Use the Skamol Lime Mortar adhesive so that unevenness does not exceed 10mm.

2 Prepare materials

Use common tools to resize and prepare SkamoWall Board for installations (e.g. electrical and plumbing). Apply Skamol Primer to the inwardfacing side of the board.

Mount the board

Apply Skamol Lime Mortar to the SkamoWall

Board and wall. Mount the boards on the wall and

push the boards up against each other.

4 Apply the plaster

Apply Skamol Primer to the outward-facing side of the board to be plastered. Choose between Skamol Lime Mortar and Skamol Smooth Plaster. Use the selected plaster to fill the joints.

- Mount the optional protection products


  If necessary, you can mount Skamol Corner and
  Skamol Mesh for extra wall protection.
- Finish the wall

  The wall can be painted, if desired.

Please note that any leftover material should be taken to your local recycling centre.



### **SkamoWall's expression**



## Preserve the architectural expression with SkamoWall



# Screw strength with SkamoWall

SkamoWall is light, has a high strength and is screw-tight. This means that you can screw directly into the board.

For loads over 2kg, we recommend using standard rawl plugs, which are easily mounted by pre-drilling in the SkamoWall Board.

- ✓ You can easily pre-drill and mount rawlplugs
- ✓ You can mill tracks for e.g. power cables into the boards





## Production of SkamoWall

### International producer of calcium silicate

SkamoWall Board is made of the lightweight material calcium silicate, which is produced by the Danish company Skamol Group.

Skamol has more than 35 years of experience with production of calcium silicate, and today exports to large parts of the world.

### What is calcium silicate?

The main constituents of calcium silicate are quicklime and microsilica, which is originally a by-product of silicon production.



cklime



Microsilica .

### **Calcium silicate production units:**

- Skamol Branden, Denmark Started production in 1983 ISO EN 9001 certified
- Skamol Opole, Poland Built in 2016
   ISO EN 9001 certified



# Technical information about **SkamoWall Board**

	Value	Unit
Bulk density (EN ISO 29470)	225 14	kg/m³ lb/ft³
Compressive strength (EN ISO 29469)	2.6 377	MPa psi
Total porosity (EN 993-1)	91	%
Water vapour transmission, µ (EN 12086)	3	
Short term water absorption (EN ISO 29767)	28 5.73	kg/m² Ib/ft²
Thermal conductivity (EN 12667), $\lambda_{23.50}$	0.068 0.039	W/(m×K) BTU/(h×ft×°F)

Sound reduction index (R <sub>w</sub> (C;C <sub>tr</sub> ))	Thickness		
	25mm	25 (-2;-4)	dB
	60mm	27 (-1;-3)	dB

Thermal resistance	Thickness	R	
	25mm	0.37	(m²×K)/W
	50mm	0.74	(m²×K)/W
	100mm	1.47	(m²×K)/W
	0.98in	2.09	(ft²×h×°F)/BTU
	1.97in	4.18	(ft²×h×°F)/BTU
	3.94in	8.35	(ft²×h×°F)/BTU

Fire classification (EN 13501-1:2007 + A1:2009)	A1*	
HS Tariff number (Harmonized Commodity Description and Coding System)	6806.90.00	
Colour	Grey	

<sup>\*</sup> SkamoWall Board's fire resistance is classified in the highest requirement level A1 according to the European fire classification system EN 13 501.

This means that the SkamoWall Board is classified as a non-flammable material.





22



Алматы (7273)495-231 Ангарск (3955)60-70-56 Архангельск (8182)63-90-72 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 Благовещенск (4162)22-76-07 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Владикавказ (8672)28-90-48 Владикавказ (8672)28-90-48 Волоград (844)278-03-48 Волоград (8472)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89 Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Иркутск (395)279-98-46 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Коломна (4966)23-41-49 Кострома (4942)77-07-48 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Курган (3522)50-90-47 Липецк (4742)52-20-81

Россия +7(495)268-04-70

Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Ноябрьск (3496)41-32-12 Новосибирск (383)227-86-73 Омск (3812)21-46-40 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Петрозаводск (8142)55-98-37 Псков (8112)59-10-37

Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78 Севастополь (8692)22-31-93 Саранск (8342)22-96-24 Симферополь (3652)67-13-56 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Сургут (3462)77-98-35 Сыктывкар (8212)25-95-17 Тамбов (4752)50-40-97 Тверь (4822)63-31-35

Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07 Томск (3822)98-41-53 Тула (4872)33-79-87 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59 Улан-Удэ (3012)59-97-51 Уфа (347)229-48-12 Хабаровск (4212)92-98-04 Чебоксары (8352)28-53-07 Челябинск (351)202-03-61 Череповец (8202)49-02-64 Чита (3022)38-34-83 Якутск (4112)23-90-97 Ярославль (4852)69-52-93

https://skamol.nt-rt.ru/ || sor@nt-rt.ru

Пермь (342)205-81-47